



- NOTES:
1. PADDLE BLIND AND START-UP STRAINER FLANGE WILL BE CONSTRUCTED TO THE SAME THICKNESS (INCLUDING GASKETS). AFTER START-UP IS COMPLETE, THE START-UP STRAINER (SUPPLIED BY VENDOR) WILL BE REMOVED AND REPLACED WITH PADDLE BLIND
  2. 40# VALVE AND HOSE CONNECTION ON CYLINDER DRAIN TO BE INSTALLED IN THE HORIZONTAL RUN OF PIPE COMING FROM COMPRESSOR BEFORE PIPE ENTERS TRENCH.

[illegible]