



R-S-T CONNECTION																	
R1		S1		T1		R2		S2		T2		R3		S3		T3	
2A	44B	2B	23A	23B	44A	65A	107B	65B	86A	86B	107A	128A	170B	128B	149A	149B	170A
5A	47B	5B	26A	26B	47A	68A	110B	68B	89A	89B	110A	131A	173B	131B	152A	152B	173A
8A	50B	8B	29A	29B	50A	71A	113B	71B	92A	92B	113A	134A	176B	134B	155A	155B	176A
11A	53B	11B	32A	32B	53A	74A	116B	74B	95A	95B	116A	137A	179B	137B	158A	158B	179A
14A	56B	14B	35A	35B	56A	77A	119B	77B	98A	98B	119A	140A	182B	140B	161A	161B	182A
17A	59B	17B	38A	38B	59A	80A	122B	80B	101A	101B	122A	143A	185B	143B	164A	164B	185A
20A	62B	20B	41A	41B	62A	83A	125B	83B	104A	104B	125A	146A	188B	146B	167A	167B	188A
R4		S4		T4		R5		S5		T5		R6		S6		T6	
191A	233B	191B	212A	212B	233A	254A	296B	254B	275A	275B	296A	314A	359B	317B	338A	338B	359A
194A	236B	194B	215A	215B	236A	257A	299B	257B	278A	278B	299A	320A	362B	320B	341A	341B	362A
197A	239B	197B	218A	218B	239A	260A	302B	260B	281A	281B	302A	323A	365B	323B	344A	344B	365A
200A	242B	200B	221A	221B	242A	263A	305B	263B	284A	284B	305A	326A	368B	326B	347A	347B	368A
203A	245B	203B	224A	224B	245A	266A	308B	266B	287A	287B	308A	329A	371B	329B	350A	350B	371A
206A	248B	206B	227A	227B	248A	269A	311B	269B	290A	290B	311A	332A	374B	332B	353A	353B	374A
209A	251B	209B	230A	230B	251A	272A	314B	272B	293A	293B	314A	335A	377B	335B	356A	356B	377A
AS SPARE PARTS LIST																	
379	380	381	382	383	384	385	386	387	388	389	390	391	392	393	394	395	396
397	398	399	400	401	402	403	404	405	406	407	408						